# DURA-METER<sup>™</sup>



## CALIBRATION

**NOTE:** Use a primed system. Verify your calibration. Fluid viscosity changes with temperature.

Calibration Select a calibration reference from the "Quick" list or choose "Calibr" for manual calibration. **OUICK LIST** Home I Help I Quick I Calibr Product names for Fill a calibrated containe reference only Press "Cont" when done Reference #1 Cancel] Help [Reset] Cont Cancel | Dn 🖶 | Up 🕈 | Select Select a thickness number. For most agricultural chemicals, 8 is a good starting point. Once the cal jug has 5 gallons in it, Press "Cont"inue button Check Pump 5 Gallons and see Adjust "Up" or Down" how close you are to match the volume in the Cal Jug Adjust Each reference number represents Enter the amount measured Press SAVE when done 1% change. If the meter reads high, lower the number. (meter 2 Gallons shows 5.25 gallons, adjust the Cancel Down I Up I Save number down 5% or 5 numbers.) **Repeat as needed** Press save & VERIFY METHOD TRAITS MANUAL OUICK LIST • Number is the same Most accurate across any Dura-Meter, Usually only takes one attempt great for fleet use Adjustable to compensate for different measurement containers; 2.5-7 Gallon

range

DURA PRODUCTS Technology with Lasting Value www.DuraProducts.com Arcadia, IN 46030 | (855) 502-3872

# DURA-ABS<sup>TM</sup> AUTO-BATCH SYSTEM

## **5 SAVED CALIBRATIONS**

This meter is equipped with the ability to save and recall five different manual calibrations. Always be aware of the cal factor or Fluid # being used and **VERIFY!** 

SAVING:

Manually calibrate. After pressing "Cont", you will be prompted to enter the fluid # where you want the calibration stored.

Choose a PreCal Number to save your fluid calibration #

(Fluid 1 ) Fluid 2 (Fluid 3 ) Next )

**RECALLING:** 

Hold down the "Cal" button. Select "PreCal" and then the Fluid #

Home [PreCal]Quick [Calib

**NOTE:** Use a primed system. Always verify your calibration. Fluid viscosity changes with temperature.

Operating Temp	-10°F to 130°F, -23°C to 54°C
Flow Rate	2 to 22GPM, 7.5 to 83LPM
Meter Accuracy	+/5%
Backlit LCD Display	Yes; with back-light timeout
Max Pressure	40 PSI
Power Source	4 "AAA" batteries; strength indicator
Nutating Disc	Yes
Wetted Materials	Polypropylene; 304 Stainless Steel; Ryton; EPDM, Viton® or Silicone seals
Housing Chamber	Polypropylene
Moisture Sealed	Yes; with sealed circuitry
Amount Metered	Yes
Batch Count	Yes
Units Measured	Gallons, Liters and Ounces
<b>Chemically Resistant</b>	Yes
Calibration	Quick List or Manual
Dimensions	5-1/4" W x 5-1/4" H x 4-1/4" D
Weight	1.5 lbs
EPA Compliant	Yes

A check valve has been included to keep •the system primed. Accuracy depends on the system staying primed.

**AUTO-BATCH OPERATION** 

Set Amount

Press start

**NOTE:** The calibration setting that is used in Auto mode, is the last calibration the meter was assigned.

3 The pump will begin to dispense fluid and automatically shuts off when complete.

PUMP SWITCH OPERATION



Manual

Auto

Pump switch must be in the ON position for Auto mode to work. Before switching to manual mode, place the pump switch in the OFF position. **Failure to do so, can result in unwanted product being dispensed**.

#### VOLUME ADJUSTMENT



Use "Up"or "Down" buttons to change amount. Scroll speed increases the longer you hold the buttons. "Reset" defaults to 10Gal, 40L, & 128Oz.