

DURA-METERTM



	Operating Temp	-10°F to 130°F, -23°C to 54°C	
	Flow Rate	2 to 22GPM, 7.5 to 83LPM	S
	Meter Accuracy	+/5%	
	Backlit LCD Display	Yes; with back-light timeout	\simeq
	Max Pressure	40 PSI	
	Power Source	4 "AAA" batteries; strength indicator	CAT
	Nutating Disc	Yes	\vdash
	Wetted Materials	Polypropylene; 304 Stainless Steel; Ryton; EPDM, Viton® or Silicone seals	CIFI
100	Housing Chamber	Polypropylene	PE
10.	Moisture Sealed	Yes; with sealed circuitry	S
	Amount Metered	Yes	
	Batch Count	Yes	CA
	Units Measured	Gallons, Liters and Ounces	\subseteq
	Chemically Resistant	Yes	Z
	Calibration	Quick List or Manual	I
	Dimensions	5-1/4" W x 5-1/4" H x 4-1/4" D	C
	Weight	1.5 lbs	Щ
	EPA Compliant	Yes	

CALIBRATION

NOTE: Use a primed system. Verify your calibration. Fluid viscosity changes with temperature.



METHOD TRAITS

OUICK LIST

• Number is the same across any Dura-Meter, great for fleet use

MANUAL

- Most accurate
- Usually only takes one attempt
- Adjustable to compensate for different measurement containers; 2.5-7 Gallon range



DURA **AUTO-BATCH**TM EASY CADDY



Operating Temp	-10°F to 130°F, -23°C to 54°C	_
Flow Rate	2 to 22GPM, 7.5 to 83LPM	S
Meter Accuracy	+/5%	
Backlit LCD Display	Yes; with back-light timeout	\succeq
Max Pressure	40 PSI	
Power Source	4 "AAA" batteries; strength indicator	
Nutating Disc	Yes	
Wetted Materials	Polypropylene; 304 Stainless Steel; Ryton; EPDM, Viton® or Silicone seals	CIFICATIO
Housing Chamber	Polypropylene	SPE
Moisture Sealed	Yes; with sealed circuitry	S
Amount Metered	Yes	
Batch Count	Yes	NICAL
Units Measured	Gallons, Liters and Ounces	
Chemically Resistant	Yes	Z
Calibration	Quick List or Manual	I
Dimensions	5-1/4" W x 5-1/4" H x 4-1/4" D	C
Weight	1.5 lbs	
EPA Compliant	Yes	

5 SAVED CALIBRATIONS

This meter is equipped with the ability to save and recall five different manual calibrations. Always be aware of the cal factor or Fluid # being used and **VERIFY!**

SAVING:

Manually calibrate. After pressing "Cont", you will be prompted to enter the fluid # where you want the calibration stored.

Choose a PreCal Number to save your fluid calibration #

(Fluid 1 [Fluid 2 [Fluid 3 | Next]

RECALLING:

Hold down the "Cal" button. Select "PreCal" and then the Fluid #.

Home [PreCal] Quick [Calibr

NOTE: Use a primed system. Always verify your calibration. Fluid viscosity changes with temperature.

AUTO-BATCH OPERATION

A 10.00

Set Amount

Press start

NOTE: The calibration setting that is used in Auto mode, is the last calibration the meter was assigned.

The pump will begin to dispense fluid and automatically shuts off when complete.

PUMP SWITCH OPERATION



Pump switch must be in the ON position for Auto mode to work. Before switching to manual mode, place the pump switch in the OFF position. Failure to do so, can result in unwanted product being dispensed.

VOLUME ADJUSTMENT



Use "Up"or "Down" buttons to change amount. Scroll speed increases the longer you hold the buttons. "Reset" defaults to 10Gal, 40L, & 128Oz.